www.m3mobile.net

M3 Sky series
Quick Manual Ver.1.4

All Information of user manual and programs can be downloaded at www.m3mobile.net

M3 MOBILE
Your Best Mobile Business Partner

FEATURES



1 Barcode Scanner Window
2 Memory Card Cover
3 Up/Down Button
4 Touch Screen
(with screen protector)
5 Speaker
6 Charging Status LED
7 Radio Status LED
8 Scan LED
9 Antenna
10 Camera Button
11 Scanner Button
12 Infrared Communication Port
(IrDA)
13 Microphone
14 Keypad
15 24pin Connector
(Only in Alpha-numeric)
16 I/O Connector
17 Stylus Pen
18 Camera Flash
19 Camera
20 Reset Switch
21 Battery Lock
22 Battery





RFID Design

LF RFID (125KHz)/HF RFID (13.56MHz)



Input Key



1 Input mode change
2 Talk
3 Left Soft Key
4 Right Soft Key
5 End
6 Power
7 Start
8 Backspace
9 Nevigation
10 Function
11 Action



1 Talk
2 Left Soft Key
3 Scan Button
4 Right Soft Key
5 Start
6 End
7 Nevigation
8 Power
9 Backspace
10 Enter
11 Microphone

Some Key functions might not be supported, depending on the option.

RESET

Soft Reset

Soft reset makes your device to get a fresh start, similar to rebooting a computer.



1. In case that back-up battery is discharged completely, the device can not be booted by power button and soft-reset. Users are supposed to press the reset button for more than 5 seconds.
2. When the abnormal working (1.white screen 2. lock-up 3. etc) suddenly happen on the LCD display and the device can not be turned on by pressing power button. Please do soft reset.(Press the reset button with stylus pen.)
3. The device in sleep mode will be waken up when the device is put on cradle.

M3 MOBILE
Your Best Mobile Business Partner

sales@m3mobile.co.kr
www.m3mobile.net

HEADQUARTER/Service Center
135-923 M3 Bldg. 735-45
Yeoksam-Dong, Gangnam-Gu,
Seoul, Korea

T.+82-2-574-0037

M3 Factory
420-120, Chuneul-Technopark II,
202 Chuneul-Dong, Wonmi-Gu,
Bucheon, Korea

T. +82-32-623-0037

copyright@m3mobile Corporation 2011 All Rights Reserved

DEVICE SETUP

SIM Card Installation



Battery Installation

Insert the Battery



-Insert the battery, bottom first, into the battery compartment.
-Press down on the battery and fasten the battery lock.

Remove the Battery



-Slide battery lock to the right and remove the battery slightly.
-Grasp the battery and lift from the M3 SKY.

Charging

Charge the M3 SKY & Battery



Charging with Portable adapter (Numeric keypad only)

MiniSD Card Installation

DATA CAPTURE

Scanning / Imaging



Scanning

Imaging

RFID Reading



ACCESSORIES

USB Cable

Battery

Cradle

2 Units of Stylus

Quick Manual

Portable Adapter